



THE LIME CENTRE

The Lime Centre Ltd, Hazeley Road, Morestead, Winchester, Hampshire SO21 1LZ
Tel: 01962 713636 | info@thelimecentre.co.uk | www.thelimecentre.co.uk

Woodfibre and Lime Plaster Internal Wall Insulation Installation onto Masonry Walls

The Woodfibre and Solo lime plaster system is designed and tested to allow solid walls to stay dry, while offering modern levels of insulation and ease of application.

Wall Preparation

- Remove any masonry paints or materials which are sealing the wall or acting as a vapour barrier.
- Externally check the pointing, paint or render is in fair condition. If not repair with suitable breathable materials (e.g. natural lime render or mortar)
- Internally, remove vinyl finishes and sealed plasters (e.g. gypsum)
- Surface must be flat, level and porous. Old smooth lime plasters should be opened by scouring or sanding. Uneven walls, bare brick or stone must be levelled with a lime plaster base coat (approx. 12mm).
- Cables etc should be chased and run in the masonry or plaster before fitting the boards.

Warmshell Woodfibre Board

- Masonry – tongue & groove wood fibre boards 1430mm x 560mm (0.8m²) per board. Depth of 40mm, or 60mm.

Fixing the boards

- The boards are fixed to the wall using Warmshell adhesive applied to the surface of the boards using a 10mm notch trowel.
- The boards are fixed in a lattice horizontally and pushed tightly together.
- They should alternate down corners.
- Vertical joints must be staggered.
- Don't line boards up with window edges, always stagger joints.
- Butt the boards up as tightly as possible.
- Cut pieces must be at least 200mm wide.
- Always insulate reveals, thinner 20mm boards may be required.
- Make sure the boards have an airtight fit around windows and doors. Use expanding foam tape if necessary.



THE LIME CENTRE

The Lime Centre Ltd, Hazeley Road, Morestead, Winchester, Hampshire SO21 1LZ
Tel: 01962 713636 | info@thelimecentre.co.uk | www.thelimecentre.co.uk

Lime Plaster on boards

- Before plastering, inspect the boards. Check they have been fixed correctly. Steps in the boards must be dubbed out with Solo lime plaster and allowed to set before applying finishing plaster. Gaps greater than 10mm between the board connections must be foam filled or packed out.
- Apply Solo lime plaster in 2 passes to a combined thickness of 8-12mm – *see separate Solo Product Data Sheet*. 1 x 25kg bag covers 1.6m² at 9mm.
- The first pass is applied approx. 5-6mm thick.
- Apply 454 glass fibre mesh, push into the plaster immediately while it is still tacky. Overlap joins in the mesh by 100mm.
- 454 glass fibre mesh is doubled up around windows and doors, with a diagonal layer applied. The diagonal piece should be at least 200mm x 400mm.
- The second pass of Solo is applied over the top usually within 4 hours to give a total thickness approx. 8-12mm thick.
- Level plaster with a straight edge and finish.
- Do not over-work the surface as this may lead to “fine cracking”.
- Allow at least 2 weeks drying time, during which time the plaster should be protected from rapid or forced drying.
- Apply in temperatures above 5°C and below 30°C.

Decoration

- The system is vapour-open and functions by allowing moisture to pass freely. It is therefore important that only vapour-permeable paints are used for decoration.
- We recommend and supply Beeck Maxol mineral paint or Earthborn Clay Paint. Contact The Lime Centre for further advice or information about breathable paints.



THE LIME CENTRE

The Lime Centre Ltd, Hazeley Road, Morestead, Winchester, Hampshire SO21 1LZ
Tel: 01962 713636 | info@thelimecentre.co.uk | www.thelimecentre.co.uk

Typical U values

U Value w/ m²K

	20mm Lime Plaster	40mm WFB & Solo	60mm WFB & Solo
215 Brick wall	1.73	0.64	0.49
330 Brick wall	1.28	0.57	0.45

(Assumed Thermal Conductivity W/mk – Woodfibre = 0.04)

